



Stage Lighting Equipment Supplier Expert

WELCOME TO JOIN US

USER'S MANUAL

LED Flat Par 54x3W VIOLET Manual



-Maintenance

1. Please keep the light in dryness and avoiding use in wet place.
2. Using intermittently can be extended the life.
3. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
4. Please do not wipe the crust using organic menstruum for avoid to damaged the product.

-Statement

The product has well capability and intact packing when leave factory, All of the user should comply with above warning item and manual, any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual.

Please forgive that we will not be notice for technical change

-Attention Item

1. For guarantee the life of product, please do not put it on the wet place and not use it the place over 40 degree.

2. Please don't lay the product on the un-fixable or shakable place.
3. Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.
4. Power supply should not be changed over $\pm 10\%$ while the light is using, it will be decreased the life of lamp if the power is too high, but it will be influenced the luminosity if the power is too low.
5. After power off, if it is need used again, please cool down over 20 minuter.
6. Please look round the manual for ensure the product can be used normally.

-DMX Channel Summary-7 Channels Mode

Channel	Value	Function
CH1	0-255	Total dimming
CH2	0-255	LED light mode 1
CH3	0-255	LED light mode 2
CH4	0-255	LED light mode 3
CH5	0-255	LED light mode 4
CH6	51-100	Program jump effect
	101-150	Program gradient effect
	151-200	Program pulse effect
	201-255	Sound control function
CH7	0-255	Strobe (CH 2/3/4/5) Function Speed (CH6)

-Display Control Instruction

No	Display	Function
1.	D.00 1	DMX mode channel address code
2.	P.24	Color jump effect

	0	
3.	L.24 0	Color gradient effect
4.	E.24 0	Color pulse effect
5.	SOU D	Sound control
6.	r.00 1	LED light mode 1
7.	G.00 1	LED light mode 2
8.	b.00 1	LED light mode 3
9.	U.00 1	LED light mode 4
10.	F.25 5	Flash Strobe
<p>Note: voice function test, attention should be paid to the level of sound sensitivity, and adjusting the driving plate to fine tune the position to get the best sensitivity to enter.</p>		

-Display Control Instruction

Welcome to use our light. The light uses energy-saving LED, long Product life, shockproof, dustproof, DMX receiver and self-running feature, which can produce a variety of vivid lighting effects, easy to operate, suitable for all types of entertainment decoration, architectural lighting industry.

Access control panel functions using the four buttons located directly underneath the LED display on the included wired remote.

BUTTON	FUNCTION
<MENU>	Used to scroll through the current operating mode, as well as back out of the current menu option
<DOWN>	Used to select decreasing advancement in the value
<UP>	Used to select increasing advancement in the value
<ENTER>	Used to select a value and store it to memory



The Control Panel shows the current state of the unit. It is used to select the operating mode, as well as the sub-features. For a detailed layout of the control panel functions, please see the "menu map" section on the following page.

Use the UP/DOWN buttons to scroll through the various menu items.

To select desired item, press the ENTER.

-Product Introduction

- ❖ Power Supply:AC90--275V,50--60HZ
- ❖ Power consumption:162W
- ❖ Fixing lamp:LED 54×3W Violet Color
- ❖ DMX-Control-channels:7 DMX Channels
- ❖ Shuttle:Flash rate:0--10HZ
- ❖ Dimmer:0-100% mechanic dimmer
- ❖ Long Lifespan LEDs(more than 60,000 hours)