

Stage Lighting Equipment Supplier Expert

USER'S MANUAL

LED Flat Par Quad 7 Light User's Manual



Maintenance

- 1. Please keep the light in dryness and avoiding use in wet place.
- 2. Using intermittenlly can be extended the life.
- 3.Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
- 4. Please do not wipe the crust using organic menstruum for avoid to damaged the product.

Statement

The product has well capability and intact packing when leave factory, All of the user should comply with above warning item and manual , any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual. Please forgive that we will not be notice for technical change

Attention Item

1. For guarantee the life of product, please do not put it on the wet place and not use it the place over 40 degree.

- 2.Please don't lay the product on the un-fixable or shakable place.
- 3.Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.
- 4.Power supply should not be changed over +&-10% while the light is using, it will be decreased the life of lamp if the power is too high, but it will be influenced the luminosity if the power is too low.
- 5. After power off, if it is need used again, please cool down over 20 minuter.
- 6.Please look round the manual for ensure the product can be used normally.

DMX Channel Summary-7 Channels Mode

Channel	Value	Function				
CH1	Total	R,G,B,W,total dimming,linear dimming form dark to light				
	dimming					
CH2	Red	Red dimming,Linear dimming form dark to Bright				
CH3	Green	Green dimming,Linear dimming form dark to Bright				
CH4	Blue	Blue dimming,Linear dimming form dark to Bright				
CH5	White	White dimming,Linear dimming form dark to Bright				
CH6	Function selection	NO Effect Auto Mode 1 Auto Mode 2 Auto Mode 3 Sound Mode				
CH7 0-255 Fun		Function Speed Adjustment -CH7 Strobe -RBGW				

Display Control Instruction

	Display Control mistraction				
No	Display	Function			
1	d001	8-channel address code, (001512)			
		B, C key addition and subtraction address code value			
2	CC01	Colorful jump, (001-99) through the [UP] key or [DOWN]			
		down key to modify the speed of the jump			

3	CP01	Colorful gradient, (001-99), through the [UP] key or [DOWN]					
		down key to modify the speed of the gradient					
4	dE00	Enter the display menu for the program demo mode, the					
		program from the walk through the [UP] key or [DOWN] down					
		key to modify the speed of the speed					
5	BEBE	The display menu to voice mode, through so <mark>und trig</mark> ger					
		transformation of a different color.					
		Note: voice function test, attention should be paid to the level					
		of sound sensitivity, and adjusting the driving plate to fine tune					
		the position to get the best sensitivity to enter					
6	R001	Red color selection, (001-255) through the [UP] up or					
		[DOWN] down key to modify the red light brightness					
7	G001	Green color selection, (001-255) through the [UP] key or					
		[DOWN] down key to modify the green brightness					
8	B001	Blue color selection, (001-255) by the "UP" key or "DOWN"					
		down key to modify the blue brightness					
9	W001	White color selection, (001-255) through the [UP] up or					
		[DOWN] down key to modify the blue brightness					

Display Control Instruction

Welcome to use our light. The light uses energy-saving LED, long Product life, shockproof, dustproof, DMX receiver and self-running feature, which can produce a variety of vivid lighting effects, easy to operate, suitable for all types of entertainment decoration, architectural lighting industry.

		Е	
A:Function			
B:Up			
C:Down			
D:Enter			
E:LED Display			

 $\mathsf{A} \qquad \mathsf{B} \qquad \mathsf{C} \qquad \mathsf{D}$

Instructions:Press the function key A cycled out the eight different function effects, digital tube first two digits on behalf of which the current function (see menu). The last two digits represent the functions in which the address code or speed parameters. Press the B or C key to modify the parameter values. Press the D key to confirm.

Product Introduction

- * Power Supply:AC90--275V,50--60HZ
- * Power consumption:84W
- * Fixing lamp:LED 7×12W RGBW
- * DMX-Control-channels:7 DMX Channels
- * Shuttle:Flash rate:0--10HZ
- * Dimmer:0-100% mechanic dimmer
- * Long Lifespan LEDs(more than 60,000 hours)