



Stage Lighting Equipment Supplier Expert

WELCOME TO JOIN US

USER'S MANUAL

Mini LED Beam 40W Lighting



Maintenance

1. Please keep the light in dryness and avoiding use in wet place.
2. Using intermittently can be extended the life.
3. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
4. Please do not wipe the crust using organic menstruum for avoid to damaged the product.

Statement

The product has well capability and intact packing when leave factory, All of the user should comply with above warning item and manual, any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual. Please forgive that we will not be notice for technical change

Attention Item

1. For guarantee the life of product, please do not put it on the wet place and not use it the place over 40 degree.
2. Please don't lay the product on the un-fixable or shakable place.
3. Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.

-
4. Power supply should not be changed over $\pm 10\%$ while the light is using, it will be decreased the life of lamp if the power is too high, but it will be influenced the luminosity if the power is too low.
5. After power off, if it is need used again, please cool down over 20 minutes.
6. Please look round the manual for ensure the product can be used normally.

Product Introduction

- * Power Supply: AC90--275V, 50--60HZ
- * Power consumption: 40W
- * Fixing lamp: LED 40W
- * DMX-Control-channels: 16/30 DMX Channels
- * Shuttle: Flash rate: 0--10HZ

-DMX Channel Summary-16 Channels Mode

Channel		Value	Function
---------	--	-------	----------

CH1	Pan	0-255	Pan X axis rotation
CH2		0-255	Pan X axis fine rotation
CH3	Tilt	0-255	Tilt Y axis rotation
CH4		0-255	Tilt Y axis fine rotation
CH5	Speed	0-255	Pan Tilt speed adjustment
CH6	Dimming	0-255	Total dimming light adjustment
CH7	Strobe	8-230	Beam Strobe
CH8	Beam	0-255	Red Dimmer
CH9		0-255	Green Dimmer
CH10		0-255	Blue Dimmer
CH11		0-255	White Dimmer
CH12	Loop	0-255	Loop Dimmer
CH13		0-255	Loop Strobe
CH14	Loop	0-127	Loop Color select
		128-135	Loop Color Auto run mode1
		136-143	Loop Color Auto run mode2
		144-151	Loop Color Auto run mode3
		152-159	Loop Color Auto run mode4
		160-167	Loop Color Auto run mode5
		168-175	Loop Color Auto run mode6
		176-183	Loop Color Auto run mode7
		184-191	Loop Color Auto run mode8
		192-199	Loop Color Auto run mode9
		200-207	Loop Color Auto run mode10
		208-215	Loop Color Auto run mode11
		216-223	Loop Color Auto run mode12
		224-231	Loop Color Auto run mode13
		232-239	Loop Color Auto run mode14
		240-247	Loop Color Auto run mode15
		248-255	Loop Color Auto run mode16
CH15	Loop Speed	0-255	Loop Auto run mode Speed
CH16	Auto Run	240-255	Auto run mode

-DMX Channel Summary-30 Channels Mode

Channel		Value	Function
---------	--	-------	----------

CH1	Pan	0-255	Pan X axis rotation
CH2		0-255	Pan X axis fine rotation
CH3	Tilt	0-255	Tilt Y axis rotation
CH4		0-255	Tilt Y axis fine rotation
CH5	Speed	0-255	Pan Tilt speed adjustment
CH6	Dimming	0-255	Total dimming light adjustment
CH7	Strobe	8-230	Strobe
CH8	Beam	0-255	Red Dimmer
CH9		0-255	Green Dimmer
CH10		0-255	Blue Dimmer
CH11		0-255	White Dimmer
CH12	Loop Color 1	0-255	Red Dimmer
CH13		0-255	Blue Dimmer
CH14		0-255	Green Dimmer
CH15	Loop Color 2	0-255	Red Dimmer
CH16		0-255	Blue Dimmer
CH17		0-255	Green Dimmer
CH18	Loop Color 3	0-255	Red Dimmer
CH19		0-255	Blue Dimmer
CH20		0-255	Green Dimmer
CH21	Loop Color 4	0-255	Red Dimmer
CH22		0-255	Blue Dimmer
CH23		0-255	Green Dimmer
CH24	Loop Color 5	0-255	Red Dimmer
CH25		0-255	Blue Dimmer
CH26		0-255	Green Dimmer
CH27	Loop Color 6	0-255	Red Dimmer
CH28		0-255	Blue Dimmer
CH29		0-255	Green Dimmer
CH30	Sound control	240-255	Loop Sound control


-Display Control Instruction

Display	Translation	Submenu	Function
---------	-------------	---------	----------

<i>Addr</i>	Address	<i>A001-A512</i>	DMX512 address setup
<i>CHnd</i>	Channel	<i>16CH 30CH</i>	16/30 channel setup
<i>SLnd</i>	Slave	<i>Nast</i>	Master and Slave mode
		<i>D512</i>	
		<i>SL 1</i>	
		<i>SL 2</i>	
<i>SHnd</i>	Sound	<i>SH 1</i>	Sound control mode
		<i>SH 2</i>	
		<i>SH 3</i>	
		<i>SH 4</i>	
<i>Auto</i>	Auto	<i>1-4</i>	Auto run mode
<i>sens</i>	sensitivity	<i>0-100</i>	Voice controlled sensitivity volume adjustment
<i>LEd</i>	LED	<i>OFF</i>	LED Display will off in 5 seconds later
		<i>ON</i>	The screen is open all the time.
<i>dISP</i>	Display	<i>no</i>	Display reverse
		<i>YES</i>	Display positive
<i>PAN</i>	Pan	<i>no</i>	Pan X motor forward
		<i>YES</i>	Pan X motor reverse
<i>tilt</i>	Tilt	<i>no</i>	Tilt Y motor forward
		<i>YES</i>	Tilt Y motor reverse
<i>ver</i>	Ver		System version
<i>rest</i>	Reset		Reset System

-Display Control Instruction

Welcome to use our light. The light uses energy-saving LED, long Product life, shockproof, dustproof, DMX receiver and self-running feature, which can produce a variety of vivid lighting effects, easy to operate, suitable for all types of entertainment decoration, architectural lighting industry.



Instructions: Press the function key A to cycle through the eight different function effects, digital tube first two digits on behalf of which the current function (see menu). The last two digits represent the functions in which the address code or speed parameters. Press the B or C key to modify the parameter values. Press the D key to confirm.