Wireless Remote Control LED Flat Par 7x18W RGBWA UV Lighting

Maintenance

1.Please keep the light in dryness and avoiding use in wet place.

2.Using intermittenlly can be extended the life.

3.Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.

4.Please do not wipe the crust using organic menstruum for avoid to damaged the product.

Statement

The product has well capability and intact packing when leave factory,All of the user should comply with above warning item and manual ,any misuse cause of the damages are not included in our guarantee,and also can't be responsible for any malfunction & problem owing to ignore the manual.

Please forgive that we will not be notice for technical change

Attention Item

1.For guarantee the life of product,please do not put it on the wet place and not use it the place over 40 degree.

2.Please don't lay the product on the un-fixable or shakable place.

3.Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.

4.Power supply should not be changed over +&-10% while the light is using,it will be decreased the life of lamp if the power is too high,but it will be influenced the luminosity if the power is too low.

5.After power off,if it is need used again,please cool down over 20 minuter.

6.Please look round the manual for ensure the product can be used normally.

Display Control Instruction

Welcome to use our light.The light uses energy-saving LED,long Product life,shockproof,dustproof, DMX receiver and self-running feature, which can produce a variety of vivid lighting effects,easy to operate, suitable for all types of entertainment decoration,architectural lighting industry.

Access control panel functions using the four buttons located directly underneath the LED display on the included wired remote.

Button	Function
<MENU>	Used to scroll through the current operating mode, as well as back out of the current menu option
<DOWN>	Used to select decreasing advancement in the value
<UP>	Used to select increasing advancement in the value
<ENTER>	Used to select a value and store it to memory

☺ WELCOME

◯ ◯ ◯ ◯
MENU   UP   DOWN   ENTER

The Control Panel shows the current state of the unit. It is used to select the operating mode, as well as the sub-features. For a detailed layout of the control panel functions, please see the "menu map" section on the following page.

Instructions:Press the function key A cycled out the eight different function effects,digital tube first two digits on behalf of which the current function(see menu).The last two digits represent the functions in which the address code or speed parameters.Press the B or C key to modify the parameter values.Press the D key to confirm.

Display Control Instruction

No	Display	Function
1	A001-A512	8 CH DMX Mode
2	rFoF-rFon	Wireless remote control On/Off
3	r001-r255	Red dimming
4	G001-G255	Green dimming
5	b001-b255	Blue dimming
6	U001-U255	White dimming
7	Y000-Y255	Yellow dimming
8	P000-P255	Violet dimming
9	Fh01-Fh99	flash, from slow to fast
10	cL01-cL08	Color selection mode
11	cc01-cc99	color jump change effect
12	dE01-cP99	colorful gradient
13	cP01-cP99	colorful gradient
14	SoU0-SoU9	Sound Mode

DMX Channel Summary-8 Channels Mode

Channel	Value	Function
CH1	0--255	Total dimming
CH2	0--255	Red dimming
CH3	0--255	Green dimming
CH4	0--255	Blue dimming
CH5	0--255	Violet dimming
CH6	0--255	Strobe from fast to slow
CH7	0-250	Auto Mode
	251-255	Sound Mode
CH8	0--255	Control speed for CH7, Auto+Sound Mode

Product Introduction

* Power Supply:AC90--275V,50--60HZ

* Power consumption:324W

* Fixing lamp:LED 18×18W RGBWA UV

* DMX-Control-channels:8 DMX Channels

* Shuttle:Flash rate:0--10HZ

* Dimmer:0-100% mechanic dimmer

* Long Lifespan LEDs(more than 60,000 hours)