



Stage Lighting Equipment Supplier Expert

WELCOME TO JOIN US

USER'S MANUAL

LED 1080x0.2W RGB Atomic Stroboscope Light



-Maintenance

1. Please keep the light in dryness and avoiding use in wet place.
2. Using intermittently can be extended the life.
3. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
4. Please do not wipe the crust using organic menstruum for avoid to damaged the product.

-Statement

The product has well capability and intact packing when leave factory, All of the user should comply with above warning item and manual, any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual. Please forgive that we will not be notice for technical change

-Attention Item

1. For guarantee the life of product, please do not put it on the wet place and not use it the place over 40 degree.
2. Please don't lay the product on the un-fixable or shakable place.
3. Ask for the professional to maintain the product in order to avoid the danger of get an electric

shock.

4.Power supply should not be changed over +&-10% while the light is using,it will be decreased the life of lamp if the power is too high,but it will be influenced the luminosity if the power is too low.

5.After power off,if it is need used again,please cool down over 20 minuter.


6.Please look round the manual for ensure the product can be used normally.

-Display Control Instruction

Welcome to use our light.The light uses energy-saving LED,long Product life,shockproof,dustproof, DMX receiver and self-running feature, which can produce a variety of vivid lighting effects,easy to operate, suitable for all types of entertainment decoration,architectural lighting industry.

Access control panel functions using the four buttons located directly underneath the LED display on the included wired remote.

BUTTON	FUNCTION
<MENU>	Used to scroll through the current operating mode, as well as back out of the current menu option
<DOWN>	Used to select decreasing advancement in the value
<UP>	Used to select increasing advancement in the value
<ENTER>	Used to select a value and store it to memory



The Control Panel shows the current state of the unit. It is used to select the operating mode, as well as the sub-features. For a detailed layout of the control panel functions, please see the "menu map" section on the following page.

Instructions:Press the function key A cycled out the eight different function effects,digital tube first two digits on behalf of which the current function(see menu).The last two digits represent the functions in which the address code or speed parameters.Press the B or C key to modify the parameter values.Press the D key to confirm.

SHEHDS

-Product Introduction

- * Power Supply : AC90--275V,50--60HZ
- * Power consumption : 216W
- * Fixing lamp : LED RGBW
- * DMX-Control-channels : 5/10/38 DMX Channels
- * Shuttle:Flash rate : 0--10HZ
- * Dimmer : 0-100% mechanic dimmer
- * Long Lifespan LEDs(more than 60,000 hours)

-Display Control Instruction

Menu	translate	Function
<i>Rddr</i>	DMX Address	Channel address code 001-512
<i>chnd</i>	Channel	5/10/38 Channel mode
<i>SLAU</i>	Slave	Slave with Other Projection
<i>SoUn</i>	Sound	Sound Control mode
<i>RUto</i>	Auto	Auto mode
<i>LEd</i>	LED	LED Display on/off
<i>dISP</i>	Display	Display upside down
<i>uEr</i>	Ver	Ver

SHEHDS

DMX Channel Summary-5 Channels Mode

Channel	Function	Value	Function
CH1	dimming	0-255	Total dimming adjustment
CH2	Strobe	0-255	Strobe
CH3	Red	0-255	Red dimming
CH4	Green	0-255	Green dimming
CH5	Blue	0-255	Blue dimming

DMX Channel Summary-10 Channels Mode

Channel	Function	Value	Function
CH1	dimming	0-255	Total dimming adjustment
CH2	Strobe	0-255	Strobe
CH3	Red	0-255	Red dimming
CH4	Green	0-255	Green dimming
CH5	Blue	0-255	Blue dimming
CH6	Auto	8-255	Auto Mode
CH7	Auto Speed	0-255	Auto Mode Speed
CH8	Color	0-255	Auto Mode Point Color
CH9	Backlight	0-255	Auto Mode background color selection
CH10	Direction	127-255	Auto Mode move Direction

DMX Channel Summary-38 Channels Mode

Channel	Function	Value	Function
CH1	dimming	0-255	Total dimming adjustment
CH2	Strobe	0-255	Strobe
CH3	1# Color block	0-255	1# Red dimming
CH4		0-255	1# Green dimming
CH5		0-255	1# Blue dimming
CH6	2# Color block	0-255	2# Red dimming
CH7		0-255	2# Green dimming
CH8		0-255	2# Blue dimming
...
Ch36	6# Color block	0-255	6# Red dimming
Ch37		0-255	6# Green dimming
Ch38		0-255	6# Blue dimming