

## USER'S MANUAL

### LED Beam 7x12W RGBW Moving Head Lighting



#### Maintenance

1. Please keep the light in dryness and avoiding use in wet place.
2. Using intermittently can be extended the life.
3. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
4. Please do not wipe the crust using organic menstruum for avoid to damaged the product.

#### Statement

The product has well capability and intact packing when leave factory, All of the user should comply with above warning item and manual, any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual. Please forgive that we will not be notice for technical change

#### Attention Item

1. For guarantee the life of product, please do not put it on the wet place and not use it the place over 40 degree.
2. Please don't lay the product on the un-fixable or shakable place.
3. Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.

- 4.Power supply should not be changed over +&-10% while the light is using,it will be decreased the life of lamp if the power is too high,but it will be influenced the luminosity if the power is too low.
- 5.After power off,if it is need used again,please cool down over 20 minuter.
- 6.Please look round the manual for ensure the product can be used normally.

## DMX Channel Summary-15 Channels Mode

Channel	DMX value	function
CH1	000-255	X
CH2	000-255	Y
CH3	000-255	X Fine
CH4	000-255	Y Fine
CH5	000-255	Dimmer(0-100%)
CH6	000-255	Strobe(0-100%)
CH7	000-255	Red(0-100%)
CH8	000-255	Green(0-100%)
CH9	000-255	Blue(0-100%)
CH10	000-255	White(0-100%)
CH11	000-255	Color change
CH12	000-255 (inner program)	0-10 before 11 channel can use 11-120 change 121-180 gradual change 181-244 mix 245-255 voice control
CH13	000-255 (inner program speed)	Jump from fast to slow 0 is fast 255 is slow
CH14	000-255(X Y Speed adjust)	from fast to slow 0 is fast 255 is slow
CH15	000-255(reset)	00-244 before 14 channel can use 245 -255 is reset
LCD DISPLAY MENU		
number		instruction

Display  
Control  
Instruction

1	DMX Address	DMX Address	<b>Display Control Instruction</b>  Welcome to use our light.
2	ADJ-R(0-255)	press the up and down keys to adjust red light brightness (0-255),press the enter to confirm	
3	ADJ-G(0-255)	press the up and down keys to adjust green light brightness (0-255),press the enter to confirm	
4	ADJ-B(0-255)	press the up and down keys to adjust blue light brightness (0-255),press the enter to confirm	
5	ADJ-W(0-255)	press the up and down keys to adjust white light brightness (0-255),press the enter to confirm	
6	Program(001)	press the up and down keys to select the inner program,press the enter to confirm	
7	Speed(0-16)	press the up and down keys to select the inner program speed,press the enter to confirm	
8	Test mode	press the up and down keys to select the voice control and slave run	
9	reset	Press the enter to reset	

The light uses energy-saving LED, long Product life, shockproof, dustproof, DMX receiver and self-running feature, which can produce a variety of vivid lighting effects, easy to operate, suitable for all types of entertainment decoration, architectural lighting industry.

E

A:Function

B:Up

C:Down

D:Enter

E:LED Display



---

A

B

C

D

Instructions: Press the function key A cycled out the eight different function effects, digital tube first two digits on behalf of which the current function (see menu). The last two digits represent the functions in which the address code or speed parameters. Press the B or C key to modify the parameter values. Press the D key to confirm.

## Product Introduction

- \* Power Supply: AC90--275V, 50--60HZ
- \* Power consumption: 84W
- \* Fixing lamp: LED 7×12W RGBW
- \* DMX-Control-channels: 7/15 DMX Channels
- \* Shuttle: Flash rate: 0--10HZ
- \* Dimmer: 0-100% mechanic dimmer
- \* Long Lifespan LEDs (more than 60,000 hours)